

## Printer Selection Help

Please select the printer using UP/DOWN arrow keys.  
For USB printer please ensure that the printer is powered on and the printer USB cable is connected to the NGIS

The inkjet printer should be PCL3 compliant.

Example:

HP DeskJet 3820v  
HP Deskjet 460C Mobile  
HP DeskJet 5440  
HP DeskJet 5550  
HP DeskJet 5650  
HP DeskJet 5740  
HP DeskJet 5940  
HP DeskJet 6122  
HP DeskJet 6540  
HP Deskjet 6940  
HP Deskjet 6980  
HP Deskjet 7360  
HP DeskJet 842C  
HP DeskJet 895Cse  
HP DeskJet 932C  
HP DeskJet 940C  
HP DeskJet 952C  
HP DeskJet 970Cse  
HP Deskjet 9800  
HP Deskjet D5160  
HP Deskjet D7160  
HP Deskjet D7360  
HP Officejet 6310 All-In-One  
HP Officejet J5780 All-In-One  
HP Officejet K550 Color  
HP Photosmart 8050  
HP Photosmart C3180 All-In-One  
HP Photosmart C5180 All-In-One  
HP Photosmart C5280 All-In-One  
HP Photosmart C6180 All-In-One  
HP Photosmart C7180 All-In-One All-In-One  
HP Photosmart 8050